



# PRO SPOT 1

## Laundry Spotter for Blood & Medicine

### PRODUCT DESCRIPTION & BENEFITS

Special stains require separate pretreatment. The **PRO SPOT 1** can handle any cleaning problem you have. **PRO SPOT 1** is formulated to clean medicines, granulex, betadine, and blood. **IMPORTANT:** Before spotting test for dye stability by cleaning a small inconspicuous section of the garment.

### DETAILED USAGE & INSTRUCTIONS

Do Not dilute. Separate items requiring pretreatment. Treat stains as soon as possible-fresh stains generally come out more easily. Follow treatment instructions to remove stain. Use care when handling all chemicals – wear appropriate clothing. Read and follow package directions when using any stain removal material. Wash hands after handling contaminated laundry. Return chemicals to proper storage area.

**BLOOD:** Flush stain for 3-5 minutes in cool – lukewarm water (not over 100°F). Wring out excess water. Saturate with spotter. Agitate with a brush or rub vigorously. Wait 5 to 10 minutes, and then launder as usual.

**MEDICINES, GRANULEX, BETADINE:** Saturate with spotter. Agitate with a brush or rub vigorously. Wait 5 to 10 minutes, and then launder in normal wash cycle without bleach.

Refer to the product label or contact a Cynamic Chemical Co. professional for additional usage instructions.

### TECHNICAL SPECIFICATIONS

Appearance / Color..... Yellow  
Odor .....Solvent  
Shelf Life .....2 years  
Solubility in Water .....Complete  
Foaming .....None  
pH .....13.5 ± 0.05  
Specific Gravity .....1.034 ± 0.005  
Storage Temperature.....45-110 °F

### FEATURES & BENEFITS

- Economical
- Specific Spotting Technique

001881

**CYNAMIC**  
CHEMICAL COMPANY

1472 Louis Bork Drive  
Batavia, IL 60510